



# Toshiba Thrive Midframe Replacement

For most parts of your Thrive to be replaced, it must be opened so you can easily get to the problem.

Written By: Kason



## INTRODUCTION

This guide will show you how to open your Thrive. Something that must be done for most repairs.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Back Cover



- Make sure the lock switch for the back cover is unlocked.
- The cover is unlocked when the switch is slid in the direction of the 'unlock' icon.

## Step 2



- Remove back cover by prying away from the Thrive.
- The easiest place to pry from is one of the two speakers.





## Step 3




- To remove the battery, make sure the lock switch is in the unlocked position.
- The battery is unlocked when the switch is slid to the unlocked position.

## Step 4






- Slide the battery switch release to the right.
- While holding the switch in place, lift up the battery.

## Step 5 — Midframe



- Start by using a screwdriver to remove the 12 screws holding on the back cover. The screws are 5mm in length and require a PH0 screwdriver.
- All of these screws are identical so don't worry about getting them mixed up.


## Step 6



- Start to gently pry the back of the device off, while leaving it loosely in place.
- Be careful not to tear or damage the cables when removing the back.



## Step 7



- Once the back of the case is off, disconnect the wires by gently pulling on the plastic tabs as shown.

## Step 8



- Carefully open the device like a book and lay the two halves beside each other.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-04 04:51:36 PM.